


# Fire Alarm Interface Events of Operation

## System Configuration for LPS WITHOUT Fire Alarm Input



## System Configuration for LPS w/ Fire Alarm Input

